

Timer

LED, Multi Function, Digital



LB4064-001 Timer – Low Voltage 12V.AC or DC

Description:

This LOW VOLTAGE multi function Timer is designed for use with Air Track Photo Gates and for general purpose lab timing where LED display is preferred for better viewing. It is high speed with resolution to 0.0001s and has several counting modes. It does not have power outlet for Photo Gates and it cannot control the IEC Solenoid Release Free Fall apparatus.

Special features are:

- High speed timing to 100 microseconds resolution.
- Large six digit LED display. Press button operation, LED indication of functions..
- Memory items can be selectively deleted to remove errors. Memory items can be scrolled, totalled or averaged.
- Remote Reset socket behaves exactly the same as the RESET press button.
- Automatic loading memory up to a depth of 20 values
- ACCURACY: All timing operations are crystal locked ensuring an accuracy of better than: 0.01% +/-1 least significant digit.

Initial Power On:

- Digital display should illuminate.
- Small LEDs indicate the Function selected.
- Press FUNCTION buttons UP/Down to select timing Function required.

Length: 185mm	Width: 100mm	Height: 35mm	Weight: 600g
---------------	--------------	--------------	--------------

INDUSTRIAL EQUIPMENT & CONTROL PTY.LTD.

61-65 McClure St. Thornbury. 3071 Melbourne. Australia
 Tel: 61 (0)3 9497 2555 Fax: 61 (0)3 9497 2166 www.iecpl.com.au



Press Button Operations:

START: initiates timing.

STOP: stops timing and value is automatically stored in memory.

RESET: If timer running, will 'freeze' display while held depressed. If timer stopped, will zero display.

MEM UP / MEM DOWN scrolls and recalls active memory locations.

Automode:

This very useful function is set by pressing STOP then RESET buttons sequentially. When set, the starting and stopping of timing will occur upon a change in status of the START / STOP electrical

connections. This excellent automatic feature can save classroom time and difficulty because there is no need to create or select 'making' or 'breaking' external connections for experiments.

Memory:

When STOP occurs by either press button or by external circuit, the last value is automatically stored into memory. When any value is stored, the small LED marked MEM lights. When the first 20 values are stored (memory full), the memory LED flashes and subsequent readings are not stored. The timer can be used normally even if the memory is full.

MEM UP/DOWN buttons scroll through the active memory store. When the first or last stored memory is reached, a longer beep sounds.

TOTAL button adds all memory values together. Press and hold until double beep is heard. Total of memory values will display whilst button is held depressed.

AVRG button calculates the average of all the memory values. Press and hold until double beep is heard. Average will display whilst button is held depressed.

PURGE button removes selected memory values. Scroll to select the unwanted value. Press and hold button until double beep is heard. Selection is now erased from memory leaving the other values untouched. Display shows '-----'.

CLEAR button empties all memory values. Press and hold button until double beep is heard. Memory store will be empty and the small memory LED will be off.

Timing Functions For External Connections:

START/STOP: When status of the START socket connections is changed momentarily the timer runs. The start connections then have no effect. When the status of the STOP connections is changed momentarily the timer stops and the value is stored into memory.

PHOTOGATE: When status of the START socket connections is changed the timer runs. When same sockets revert to original status the timer stops and the value is stored in memory. The sockets also provide the power required to run most photogate circuits.

PERIOD: When the status of the START socket connections is changed the timer runs. When same sockets revert to their original status there is no effect. When same sockets are changed again, the value is stored in memory, display is reset and the next period is started, effectively this is the time or period between successive Starts. Press STOP to stop timing.

PENDULUM: When the status of the START socket connections is changed the timer runs. When same sockets revert to original status there is no effect. When same sockets are changed and reverted again, there is no effect. Upon the fifth change, the value is stored in memory, the timer is reset and then starts timing the next pendulum period. Press STOP to stop timing. Effectively this is a double 'PERIOD' which occurs during a complete pendulum swing through a photogate.

REMOTE: duplicates the RESET and Memory Clear button function. Using a long cable, this socket can be joined to the common or 'GRND' socket by a switch or press button to create a REMOTE RESET control. As with the Reset button, this socket will clear the memory locations if joined to 'GRND' until two beeps are heard.

Designed and manufactured in Australia