


Stopwatch

OPERATION INSTRUCTION




NOTE:

Pushing MODE switch once will change from TIME mode into CHRONOGRAPH mode, pushed twice into ALARM SET, pushed triple into TIME SET or vice versa.


(I) TIME / ALARM MODE

12 HOURS and 24 HOURS DISPLAY




MONTH / DAY DISPLAY

Depress and hold DATE switch for Month / Day display.



ALARM / CHIME FUNCTION

To turn on ALARM, push and hold ADVANCE button and pushing SELECT button once.



To turn off ALARM, push and hold ADVANCE button and pushing SELECT button once again.




To turn on CHIME, push and hold ADVANCE button and pushing MODE button once and then all function bars will be show on display. Chime will be on for every hour.

To turn off CHIME, push and hold ADVANCE button and pushing MODE button once again.

(II) CHRONOGRAPH MODE

Push START / STOP button once to start counting up.



Push START / STOP button once to start counting. To restart, simply push START again.



Accumulative counting up is possible if counter is not being reset.



NOTE:

The 1/100 second mark flashes until counter exceeds 30 minutes, and afterward, display format changes to read as HOUR, MIN and SEC.

LAP FUNCTION

When chronograph is running, push LAP switch to display LAP time. LAP indicator flashes and digits stay steady, but chronograph keeps on counting. Running time can be redisplayed by pushing LAP switch again.



RUN

Chronograph can only be reset when in STOP and LAP released state.



LAP

(III) ALARM SETTING

In all subsequent setting states, digit advances by one count for every push of ADVANCE switch. Automatic advance will be performed by keeping S1 depressed.

For 24 hours mode, Indication H means 24 hours mode. For 12 hours mode, Indication A means AM and Indication P means PM.

Press S3 for twice for TIME SET



Push S2 for HOUR SET

Push S2 again for MINUTE SET



Push S3 to exit from ALARM SET mode

NOTE:

After adjusted digit of ALARM, alarm function will be turned on automatically.

3

(IV) TIME SETTING

In all subsequent setting states, digit advances by one count for every push of ADVANCE switch. Automatic advance will be performed by keeping S1 depressed.

Press S3 for triple for TIME SET



Push S1 to reset second counter only

Push S2 for MINUTE SET.




Push S2 for HOUR SET.



For 12 hours format, keeping S1 to adjust hour, hour counter will counting from 24 hours format into 12 hours format or vice versa.



Push S2 for DATE SET



Push S2 for MONTH SET




Push S2 for WEEK SET



Push S3 to exit from SET mode

REPLACEMENT OF BATTERY



Lift up battery cover to replace battery. Battery size is UM-3 (AA). Polarity should be observed. After replacing battery, time set is normally required.

5

PM104011-2